

Country Code Fitting Instructions



Clean and dry the panel area on port side of the sail with window cleaner.



Lay the flag graphic into the centre of the panel.



Measure the bottom of the flag graphic level to the batten pocket.



Tape the flag graphic in place vertically through the middle with masking tape. Make sure it is secure.



Peel back one half of the flag graphic from its backing paper.



Cut away the backing paper parallel to the masking tape.



Remove cut off paper.



Rub down half of the flag graphic with an unwanted credit or store card.



Remove vertical masking tape, then remove backing paper.



Rub down remaining half of the flag graphic.



Carfully remove the protective top paper. The vinyl can be gently heated with a hair-dryer and rubbed down with a clean dry cloth to help improve adhesion.

Repeat this process for number panel.



